




FUNCTION OF THE CONTROLS




MACHINE START UP




SELECT PROGRAM




LOADING DISHWASHERS




RUNNING A CYCLE




END OF SHIFT: FILTER CLEAN



END OF SHIFT: DRAINING DISHWASHERS



WEEKLY MAINTENANCE



SELF DIAGNOSTICS

If the dishwasher displays a fault code refer to the User manual for further information (example: *Er-D i*).

SERVICE & DETERGENTS

To request service, detergents or rinse additive contact your local Rhima service centre below:

Australia: **1300 347 944**

New Zealand: **0800 902 054**

Singapore: **+61 1300 347 944**